



Right Chair™

Multi-tilt

1. Independent Lumbar



..... 9. Arm Height

2. Forward Tilt-stop

..... 8. Arm Width

3. Back Angle
rear lever

..... 7. Seat Slider (Depth)

4. Seat Height
middle lever

..... 6. Seat Tilt Tension

5. Seat Angle
front lever

Adjusting the Multi-tilt, Right Chair™

1. **Independent Lumbar** - To position lumbar height, locate the support inside the backrest frame and move it up or down in a 3" range of motion.
2. **Forward Tilt-stop** - Your chair can be set to tilt forward, past horizontal and locked in position. Before adjusting, recline the seat slightly. Rotate the control rod to allow variable degrees of forward tilt.
3. **Back Angle** - Seated upright, lift the back angle lever and position the backrest as you choose. Then release the lever to lock it. This lever will lock in a free-float mode.
4. **Seat Height** - Lift the lever while not seated to increase height. Lift the lever while seated to decrease height.
5. **Seat Angle** - Lift the lever to release the seat. If you desire a rocking mode, lift the lever fully upward. Push the lever down again to lock seat tilt.
6. **Seat Tilt Tension** - Twist the control forward to increase tension or rearward to decrease tension
7. **Seat Slider (Depth)** - While seated, lift the lever to slide the seat forwards and backwards. This is usually a one time adjustment.
8. **Arm Width** - Easily adjusted from the seated position. Snap the latch open (away from arm) to unlock, and then position the arm to as desired. Snap the latch closed again to secure that setting.
9. **Arm Height** - For armrest height, locate the button on the outer arm support and squeeze it while positioning the arm, and then release to lock into your chosen setting.